



DRADER

INJECTIWELD

MODEL **W30000**

Instruction Manual & User Guide



Table of Contents

Congratulations on your purchase of Drader Manufacturing's plastic welding equipment	3
1. Read These Instructions to Protect Yourself and Others.....	4
2. General Information.....	4
3. Safety.....	5
4. New Welder Details	6
5. Parts and Service.....	6
6. Operating Instructions	7
Unpack the welder and inspect the contents	7
The heated barrel and tip system	8
Welding Tip Selection	8
Changing tips – The welder should be hot, but turned off	9
Connect the air supply.....	10
Plug the welder into an appropriate electrical outlet	11
Set the temperature, then turn the welder on	11
Temperature settings – Drader Injectiweld.....	12
Feed the welding rod into the welder.....	13
Make Welds	14
7. Proper Welding Techniques – General Considerations	15
8. Proper Welding Techniques – Drader Injectiweld	16
9. Proper Welding Techniques – Drader Injectiweld – Fillet welds	17
10. Proper Welding Techniques – Drader Injectiweld – Butt Welds.....	18
11. Daily Maintenance – Drader Injectiweld	19
12. RoHS and WEE compliance on Drader Injectiweld Products.....	20

To ensure safe work practices and correct operation of the **W30000 Injectiweld**, the manufacturer strongly recommends before welding, all operators read this manual.

Congratulations on your purchase of Drader Manufacturing's plastic welding equipment.

To get the most out of your purchase, be sure to read this manual carefully and keep it on hand for future reference. The Injectiweld plastic welding system uses a combination of heated tip and injection pressure to form its welds. The hot (interchangeable) tip melts the surface of the plastic and creates a weld zone into which molten plastic is injected. There is a physical mixing of the weld bead and the plastic.

While every effort has been made to ensure the information in this manual is accurate and complete, in no event shall our company be liable for any direct, indirect, punitive, incidental, special consequential damages, to property or life, whatsoever arising out of or connected with the misuse of our products. Drader Manufacturing reserves the right to change the specifications of the products described herein at any time without written notice.

1. Read These Instructions to Protect Yourself and Others

Be aware, serious injury or death may result if welding equipment is not properly installed, used, and maintained. Misuse of this equipment and other practices can be both hazardous and dangerous to the operator and any persons in the general work area. The operator and supervisor must read, and understand the following safety warnings and instructions before using this welding equipment.

The Drader Injectiweld is to be operated by qualified people in accordance with this manual. Only authorized service personnel should perform any maintenance that requires opening the welder housing.

Opening the welder housing voids the Drader Warranty.

2. General Information

Information, presented in this manual should be read, understood and followed for the safe and effective use of this equipment. Safety instructions specially pertaining to this unit appear throughout this manual, highlighted by a symbol that identifies levels of hazard. There are also welding tips and hints throughout this manual that will make your welds better and your welder usage more effective.

Symbols used throughout this manual:



HIGH VOLTAGE - The lightning flash symbol will alert the user to the presence of "dangerous voltage" that may be of sufficient magnitude to constitute a risk of electric shock.



HOT SURFACE - The heat symbol will alert the user to the fact that they might get a serious burn if they touch the part.



WARNING / CAUTION - The exclamation point symbol will alert the user to important operating and maintenance instructions.




TIP - The Injectiweld symbol identifies tips and hints to obtain the most efficient operation of this tool.

3. Safety

The operation, maintenance and troubleshooting of the Injectiweld requires practices and procedures which ensure personal safety and the safety of others.


Read and follow the safety instructions in this manual.




The Injectiweld is equipped with a ground-contact plug. The Injectiweld must be plugged into an outlet that is properly installed and grounded. If you do not know if your power outlet is grounded, check with a qualified electrician. Do not modify the plug. If it will not fit the outlet, have the proper outlet installed by a qualified electrician.



Never touch the welding tip at any time, unless you are sure that it is cool. **Severe burns may result.** Wear heat resistant gloves when handling hot welder parts.



Always unplug the unit before examining it or when leaving the welder unattended. Air line may remain connected to cool the welder.



Never allow the welder's hot tip to touch the power cord as it could melt the wire's insulation and cause a dangerous condition. Purchase a replacement cord if your hot tip touches the power cord.



Protect your eyes from hot plastic. While operating the welder, wear safety glasses.



Consider your work environment. Do not immerse the welder in water, expose it to rain, or use it in excessively damp or wet environments.



Use the welder in well ventilated areas. Some plastics may give off noxious gasses as they melt. Know the plastic that you are working with and use breathing protection if warranted.

Keep the work area well lit and clean for maximum safety.

Use only certified Drader replacement parts.

4. New Welder Details

Please fill out the information below for future reference. **Once completed, photocopy this page and fax it or email it to Drader Manufacturing. This will register your welder.**

Company Name: _____

Serial Number: _____ **Date of Purchase:** _____

Name of Distributor (if applicable): _____

Technical Data:

Model:	W30000	Air Requirements:	Min. 80 psi, Max. 100 psi Min. 5.5 bar, Max. 6.9 bar
Power:	120 Volt / 60 Hz 240 Volt / 50 Hz	Rod Diameter [Ø]:	5/32 inch (.156) 4 mm
Watts:	400 Watt	Fuse Rating:	1 x 4A Fuse (120 Volt) 1 x 2A Fuse (240 Volt - UK model) 2 x 2A Fuse (240 Volt - all others)
Weight:	4.4 lb 2.6 Kg	Max Output (HDPE):	2 lb per hour 0.9 kg per hour
Temperature Range:	392 °F - 572 °F 200 °C - 300 °C	Warranty:	One year - parts and labour
Air Consumption:	4 cfm @ 90psi 0.113 m3 @ 6.2 bar		

5. Parts and Service

Call Drader Manufacturing (or your distributor) if you need to purchase parts, or to have your welder serviced. Have the welder serial number on hand.

Head Office

Drader Manufacturing Industries Ltd.

5750 – 50 Street
Edmonton, AB T6B 2Z8, Canada

Tel: +1 780 440 2231

Toll Free (North America): 800 661 4122

Fax: +1 780 440 2244

csimpson@drader.com

www.drader.com

Service Centre

(For US Clients only)

Drader Service Centre
6825 S. Kyrene Rd
Tempe, AZ 85283
USA

Your Distributor

6. Operating Instructions

This section will provide you with an overview of using the Injectiweld. Follow these steps to learn how to operate your welder.

- Unpack the welder and inspect the contents
- Select welding tip
- Connect the air supply
- Plug the welder into an appropriate electrical outlet
- Set the temperature, then turn the welder on
- Feed the welding rod into the welder
- Make welds

Unpack the welder and inspect the contents.

#	Description	Item ID #	#	Description	Item ID #
1	W30000 Injectiweld	Unique serial number	8	Stick Scraper	IPAR-A-SCRSTK
2	Barrel Washer	IPAR-A-BARWSH	9	Air Filter Assembly	IASS-A-AIRFLT 2
3	3/16" Fillet Weld Tip	ITIP-2F6	10	Screw Driver	IPAR-A-SCREWD
4	Repair Tip	ITIP-2RP	11	4AMP Fuse 2AMP Fuse	IPAR-A-FSEALL IPAR-A-FSE2A
5	Tip Nut Wrench	IPAR-A- TIPWRN	12	Heat Transfer Compound	IPAR-A-HTTRCO
6	Tip Nut	IPAR-A-TIPNLO	Quick Manual (not shown)		
7	Scraping Blade	IPAR-A-SCRBLD	Carrying Case (not shown)		IPAR-A-CASE



The heated barrel and tip system:



#	Item ID	Description
1	IPAR-A-BARW30	W30000 Barrel
2	Shop Supply	Indexing Pin
3	IPAR_A_RTDSE4	RTD Sensor
4	Various ID Numbers	Heater

Please note, there are other barrel parts that are not listed here.

Welding Tip Selection

The correct tip will make a difference on the quality and appearance of the weld. There are different tips for various applications. The two welder kit tips are the repair tip (photo #3) and the 3/16" fillet weld tip (photo #5).



#	Description	Item ID	Main Usage
1	Blank Tip	ITIP-2BL-5.5	Custom tips; design your own for your special application
2	Prototyping Tip	ITIP-2PR	Prototyping, repairs, filling holes, spot welding tight areas
3	Repair Tip	ITIP-2RP	Repairs, filling holes, spot welding tight areas, prototyping
4	Bull Nose Tip	ITIP-2BN	Repairs, filling holes, filling voids
5	3/16" Fillet Weld Tip-Legacy	ITIP-F316LEGACY	90° fillet welds, butt welds, repairs
6	1/4" Fillet Tip	ITIP-2F4	
7	3/8" Fillet Tip	ITIP-2F8	
8	1/2" Fillet Tip	ITIP-2F5	
9	5/8" Ribbon Weld Tip	ITIP-2RW	Sealing; re-enforcement; non-pressure welds
10	3/16" Fillet Weld Tip-New Style	ITIP-F316	90° fillet welds, butt welds, repairs

The Injectiweld kit comes with 2 tips. Both tips are versatile and can provide the operator with numerous types of welds. Tip choice is important as it determines the type of plastic weld. Use this manual to assist you in your tip choice.

Changing tips – The welder should be hot, but turned off.



The tip and barrel will be hot. **Wear protective gear to protect yourself from burns.**



When removing the tip nut, do not use excessive force. Excessive force will twist the barrel and ruin it, the heater, and the RTD sensor.



The tip must be hot before changing, but the welder should be off. The tip needs to be hot in order to melt the plastic in the transition area between the tip and the barrel. If the tip nut is hard to loosen, wait 3 to 5 minutes, then try again. Tip nuts have a different expansion ratio than barrels.

Use heat transfer compound frequently. Heat transfer compound makes it easier for the barrel heat to transmit to the tip as well as to remove the tip nut. Apply the compound at every tip change or every 8 hours of operating time.

Use a copper, or brass brush to clean away burned heat transfer compound. Clean parts make heat transfer more efficient.

Make sure you always use the Barrel Washer (IPAR-A-BARWSH). It goes between the barrel and the tip.

- Place the welder on a flat, stable surface, with the on/off button facing up.
- Loosen the tip nut (IPAR-A-TIPNLO) with the tip nut wrench (IPAR-A-TIPWRN).
- Turn the tip nut wrench counter clockwise, until the tip nut is free.
- Using pliers, take the tip nut off and place it on a heat resistant surface.
- Using pliers, pull the tip from the barrel and place it on a heat resistant surface.
- Separate the barrel washer (IPAR-A-BARWSH) from the tip.
- Use a copper, or brass brush to clean the old heat transfer compound from the barrel, barrel washer, and tip.
- Open the bottle of heat transfer compound (IPAR-A-HTTRCO) and apply the compound onto the welder barrel threads, both sides of the barrel washer, and on the tip's collar. Since the welder is hot, there might be smoke from the heat transfer compound. **Be careful not to inhale fumes.**
- Place the barrel washer onto the barrel. The small hole on the barrel washer goes over the barrel's indexing pin. **There must always be a barrel washer between the barrel and the tip.** The barrel washer blocks molten plastic from backing up into the barrel.
- The tip goes next onto the barrel. The locating pin fits into one of the tip's holes.
- Slide the tip nut over the tip, and screw it onto the barrel using the tip nut wrench.

Connect the air supply.



Never use air compressors with automatic oiling systems. Too much oil in the compressed air will cause damage to the printed circuit board and to the air valve.



Keep the compressed air as dry and oil free as possible. Always use the Drader supplied air filtration units and keep them well maintained.

The Drader Injectiweld, Model W30000 requires compressed air. The welder operates at 90 psi (6.2 bar) and consumes 4 cfm (113 lt) at maximum output. The air compressor requirements are:

- **Air pressure:** Minimum: 80 psi (5.5 bar), Maximum: 100 psi (6.9 bar)
- **Horsepower:** At least 1.5 horsepower per welder (1120 Watt)

The W30000 kit ships with an air filter assembly. The filter helps to remove particulate, water and oils from the compressed air. Use it at all times.

- The Air filter assembly attaches directly to the welder's air line.

Air Filter Assembly (IASS-A-AIRFILT 2)

#	Description	Code
1	Quick Disconnect Fitting	IPAR-A-FITQUICKF2
2	Air Filter Unit	IPAR-A-AIRFILT2
3	Air Line Fitting	IPAR-A-ARFITN2




From Compressor

Plug the welder into an appropriate electrical outlet

- Plug the welder in the appropriate electrical outlet (120V or 240V).

Set the temperature, then turn the welder on.



The temperature control is a dial that does not rotate more than 3/4 of a turn. Overturning the dial will damage the temperature dial. Only authorized people should touch the temperature setting dial. Do not exceed the MIN/MAX limits.

- Set the temperature on the welder using the Drader screwdriver. Gently turn the dial to the required temperature mark. The next page has some suggested temperature settings.
- Turn the On/Off switch on.
- When first turned on, the LED will start off solid **RED**, then, as the welder heats towards the set temperature, it will start flashing **RED and GREEN**. At the set temperature, the LED will turn solid **GREEN**.
- During operation, the LED will alternately switch between **GREEN** and/or **RED** when it is maintaining the set temperature.
- Above set temperature or out of range (**LED OFF**) LED will go to **GREEN** as temp falls.



The high temperature cutoff switch [HTCO] may shut the unit off if the temperature inside the welder housing exceeds the temperature limit. Once the welder cools off, the unit will operate normally. This feature should not be used on purpose.



Proper temperature is crucial for high quality welds. Set the proper temperature.

If you change welding materials and decrease the temperature, by the time you purge the original welding rod from inside the barrel, the welder should be cool enough to resume welding at the right temperature. If in doubt about the temperature, wait a few minutes.

If the Injectiweld is not being used for a period of ½ hour or more, either **turn the welder off or turn it down to the lowest temperature level.**

Temperature settings – Drader Injectiweld

Please contact your Drader representative before using a material that is not listed below.

Material	Description	Temperature in °C	Temperature in °F
HDPE	High Density Polyethylene	265 °C	509 °F
LLDPE	Linear Low Density Polyethylene	265 °C	509 °F
HMWPE	High Molecular Weight Polyethylene	280 °C	536 °F
PP	Polypropylene	280 °C	536 °F
ABS	Acrylonitrile Butadiene Styrene	265 °C	509 °F
HIPS	High Impact Polystyrene	255 °C	491 °F
PA 6*	Polyamide	300 °C	572 °F
PC*	Polycarbonate	300 °C	572 °F
TPU	Thermoplastic Polyurethane	300 °C	572 °F

** Requires butane pre-heater. Please contact Drader for more details.*



WARNING / CAUTION - Do not use PVC [Polyvinylchloride] with the Injectiweld. The temperature and pressure used by the Injectiweld will degrade PVC and chlorine gas will be released. This aggressive gas is harmful and it can damage the aluminum parts of the welder.

Feed the welding rod into the welder

The Injectiweld Model W30000 accepts 0.156-inch (4mm) diameter welding rod. The feed is automatic once the welding rod is properly fed into the welder.

- Turn the rod release knob until the knob feels tight. This opens the rod drive wheels and allows them to accept welding rod.
- When the welder is powered up and the desired temperature is reached, feed the welding rod into the rod feed tube and push it up into the welder until it comes to a stop.
- Turn the rod release knob until the knob feels loose. This locks the rod into the feed mechanism.
- Depress the trigger and the welding rod should feed automatically into the welder.
- To remove the welding rod, turn the rod release knob until it is tight, then gently tug on the welding rod out of the welder.



Do not operate the welder without plastic welding rod. Running the welder without welding rod may result in feed mechanism damage.



When finishing off a roll of welding wire, remove the last remaining welding rod from the welder and start a fresh roll. This will reduce the chances of a rod jam.

When switching from one welding rod to another, clear the previous rod material by removing it from the feed tube, then feed the new welding rod. Let the welder pump out about one meter (one yard) of molten welding rod to ensure old material has been purged.



If the welding rod does not feed, make sure the rod release knob is loose, depress the trigger then apply gentle pressure on the welding rod, pushing it into the welder. The feed mechanism will grab the welding rod and start the automatic feed.

The rod release knob rotates 360+ degrees. When the knob feels loose, the welding rod is locked into the feed mechanism. When the knob feels tight, the welding rod is not locked into the feed mechanism.

Different types of welding rod (i.e. polyethylene, polypropylene, polycarbonate, ABS etc, have different durometers. Because of this, slightly undersized welding rod is better than oversized welding rod. With very hard welding rod (i.e. polycarbonate, try 1/8 inch (3.2mm).


Make Welds

Fillet Welds



Fillet tips are used mainly for fillet welds [90°] and butt welds. The style of those tips allows one to weld from inside corners out and be able to seal the corners without changing to another tip style. Fillet tips can also be used for crack repairs, as long as the crack is somewhat straight. The longer preheat section allows faster welding speed than welding cracks with the conical tip.

Repair Tip, Prototyping Tip



Repair tips are used for crack repairs, filling small holes, spot welding, for reaching tight areas, and for prototyping. Because of their conical shape, the repair tip and prototyping tip offer similar types of welds. Choose the size that best suits your application.



Ribbon Weld Tip

The Ribbon weld tip is used to make a seam weld on thermoplastic materials such as belting and thin sheets. Because this welding tip does not weld down to the root side, it should not be used for regular butt welds.

7. Proper Welding Techniques – General Considerations

Consider these variables when welding plastics.



Material

In order to achieve quality welds, ensure that the welding rod matches the parent material. For example, match polyethylene with polyethylene rod and match polypropylene with polypropylene rod.




Do not expect a quality weld if the parent material and welding rod do not match.



Heat

Each plastic melts within a certain temperature range. When you drift outside this zone, the weld quality diminishes.

Some people turn up the heat in order to weld faster, yet they sacrifice weld strength. Do not be tempted to weld faster by raising the weld temperature!



Pressure

Pressure allows the plastic molecules of the materials to mix. Best bonding occurs when there is a physical mixing of the plastics.

Pressure, when too high or too low, reduces weld quality.




Time

Plastic needs time to melt and time to cool down. Do not speed up the cooling time. After welding, plastic molecules need 24 hours to come to a complete rest.



Plastic should be at “room temperature” for at least 24 hours before it is welded.

8. Proper Welding Techniques – Drader Injectiweld



Welding from one side


- Butt welding two sheets together
- Plastic crack repair

Bevel each side of the plastic so that their combined angle is 90 degrees.

You may use the stick scraper to give you the proper angle.

Leave a gap between the parent materials so that molten welding rod can penetrate the root.

Excess welding rod may be trimmed off (after it cools). You may use the scraping blade to perform this function.



Welding from two sides

- Fillet welding two sheets together


The amount of welding rod injected onto the parent material should be about 70% of the thickness of the plastic sheet.

Increase or decrease welding rod thickness by:


- Changing tips
- Adjusting speed control bolt
- Adjusting the speed of how fast your welder travels

9. Proper Welding Techniques – Drader Injectiweld – Fillet welds


Fillet Welds – Correct Alignment



Welding tip is in correct alignment when it is at a 45° angle




Welding tip is in correct alignment when it is at a 45° angle




Welding tip is in correct alignment when it is flat against both sides of the parent plastic material



Welding tip is in correct alignment when it is flat against both sides of the parent plastic material




When welding from one side, leave a root gap of 0.8 to 1.5mm so that welding rod can penetrate to the other side




Welding rod should penetrate to the root side of the parent plastic

Fillet Welds – Incorrect Alignment


Welding tip is not incorrect alignment when the fillet weld tip is not at a 45o angle or when it does not come into contact with both sides of the parent plastic material




Welding tip is not in correct alignment when it does not come into contact with both sides of the parent plastic material




Welding tip is not in correct alignment when the bottom edge is not flat against the parent plastic material




Welding tip is not in correct alignment when the bottom edge is not flat against the parent



Lack of penetration to the root will result in a poor weld




Since molten welding rod did not penetrate the root, a poor weld will result




10. Proper Welding Techniques – Drader Injectiweld – Butt Welds


Butt Welds – Correct Alignment




Welding tip is in correct alignment when it is at a 90° angle




Welding tip is in correct alignment when it can reach the root of the other side of the parent plastic




Welding tip is incorrect alignment when its edges contact each side of the parent plastic material



Welding tip is in correct alignment when molten welding rod penetrates the root of the parent plastic material




If welding from one side, welding rod must fill the root of the parent plastic material




If you can weld from both sides, make two 90° bevels before welding


Butt Welds – Incorrect Alignment




Welding tip is not in correct alignment when it is not at a 90° angle



Welding tip is not in correct position when its melting surface does not contact the plastic




Welding tip is not in correct position when its melting surface does not contact the plastic



Welding tip is not in correct alignment if molten welding rod cannot penetrate the root



A poor weld because molten welding rod did not penetrate the root.



Lack of penetration will result in a poor butt weld

11. Daily Maintenance – Drader Injectiweld



A well-maintained welder will give you years of service. Follow the steps in this section to take care of your welder.

Compressed air should be as dry and clean as possible. Use the air filtration system supplied with the welder. Use of an air compressor with a dryer / dehumidifier is recommended.

Use heat transfer compound frequently. Heat transfer compound makes it easier for the barrel heat to transmit to the tip, as well as to remove the tip nut. Apply the compound at every tip change or every 8 hours of operating time.

Use a copper (or brass) brush to clean away burned heat transfer compound. Clean parts make heat transfer more efficient.

At the beginning of each shift (or every 8 hours of welder operation):

- Turn welder on and bring up to heat.
- Turn welder off, unplug it from the electrical socket then wait 2 - 3 minutes. (This allows the aluminum barrel to shrink smaller than the steel tip nut).
- Remove tip nut, tip and barrel washer. Be careful – they will be very hot!
- Using copper or brass brush, clean the old heat transfer paste from the tip nut, tip, barrel, and barrel washer.
- Apply a new layer of heat transfer compound to the tip, barrel, and barrel washer.
- Reassemble the welder by placing the barrel washer onto the barrel first. Then place the tip onto the barrel, followed by the tip nut. Use the tip nut wrench and hand tighten the tip nut. Do not tighten the nut too much.
- Plug the welder in, and then turn it on. Bring it up to the set temperature, and then commence welding.
- Make sure the tip nut is snug periodically throughout the day.

12. RoHS and WEE compliance on Drader Injectiweld Products



Drader Manufacturing products that comply with the European Community directive 2002/95/EC with respect to the restriction of hazardous substances in electrical and electronic equipment. EU products will be marked with this RoHS symbol.



Drader Manufacturing is compliant with the European Community directive 2002/96/EC (Waste Electrical & Electronic Equipment, WEEE) with respect to products sold within the European Union. This directive restricts the disposal of electronic equipment and states that it must be marked to indicate it is not to be disposed of in unsorted waste starting August 13, 2005. This marking has been added to Drader products sold in the EU.

13. Warranty

A. Warranty

Drader Manufacturing Industries Ltd. (“**DRADER**”) warrants new W30000 Injectiweld Welders manufactured by DRADER (the “**Welder**”) and any new accessories and replacement parts for the Welder (the “**Parts**”) (the Welder and the Parts hereinafter collectively referred to as the “**Injectiweld Products**”) against manufacturer defects in workmanship and materials under normal use and conditions for a period of 1 year (“**Warranty Period**”) from the date of first purchase from DRADER or an authorized distributor of Drader (“**Authorized Distributor**”). Customer shall, prior to making a warranty claim, first utilize support materials shipped with the Injectiweld Products, product diagnostics, information contained on the internet and e-mail support.

If there is a manufacturer defect in any of the Injectiweld Products (such defective Injectiweld Products hereinafter referred to as the “**Defective Products**”), as determined by DRADER in its sole and unfettered discretion, and a written claim is received with respect to the Defective Products by DRADER or an Authorized Distributor prior to expiry of the Warranty Period, then, at DRADER’s option, DRADER will either:

1. repair the defect in material or workmanship with respect to such Defective Products; or
2. furnish new, repaired or refurbished Injectiweld Products (such Injectiweld Products to be for the same purpose as the Defective Products) of equal value, in exchange without charge (except for fees associated with shipping, handling, packing and insurance as provided herein).

DRADER warrants repaired and replaced Defective Products provided hereunder against defects in materials and workmanship from the date of the repair or replacement for the remainder of the original Warranty Period. If the Defective Products are exchanged, the replacement Injectiweld Products become the customer’s property and the Defective Products become DRADER’s property. The customer is responsible for all costs of shipping the Defective Products to DRADER and DRADER shall be responsible for the cost of returning the repaired Defective Products or replacement Injectiweld Products (whichever is applicable) to the customer only if the warranty claim is deemed to be valid as provided herein (if the warranty claim is rejected by DRADER, the customer will be charged for the cost of all authorized repairs/replacements as well as shipping the Defective Products and/or Injectiweld Products back to the customer). Shipping for warranty claims handled by an Authorized Distributor will be handled in accordance with the Authorized Distributor’s standard policies and procedures regarding shipping warranty repaired products, which may differ from those of DRADER.

B. Warranty Exclusions

The limited warranty provided herein is non-transferable, applies only to new Injectiweld Products purchased directly from DRADER or from an Authorized Distributor and is only available in the event the customer uses the Injectiweld Products under normal operating conditions as provided in written use instructions, if any (either in writing with the Injectiweld Products or online as provided by DRADER).

1. The limited warranty provided herein shall not apply to any Injectiweld Products, and DRADER shall not be

obligated under this warranty, to repair any defect, failure or damage to Injectiweld Products which, in the sole and unfettered discretion of Drader, are in any way the result of:

- (a) Accident, abuse or improper use of the Injectiweld Products;
- (b) Attempts by personnel, other than personnel of DRADER, to install, repair or service the Injectiweld Products unless directed by DRADER personnel and confirmed in writing;
- (c) Modifications or alterations not approved by DRADER in writing;
- (d) The customer failing to properly or adequately maintain and clean the Injectiweld Products as prescribed in published product materials and industry norms; and
- (e) Using the Injectiweld Products in an environment not meeting the operating specification set forth by DRADER for the Injectiweld Products.

2. In addition to the exclusions provided in Paragraph B1 above, the limited warranty provided herein does not:

- (a) Apply to previously used Injectiweld Products;
- (b) Apply to any Injectiweld Products where the serial number or the serial number of any of its parts has been altered, defaced, or removed;
- (c) Apply to labels on the Injectiweld Products;
- (d) Apply to normal wear and tear of the Injectiweld Products;
- (e) Cover damage or loss incurred in transportation of the Injectiweld Products;
- (f) Cover replacement or repair necessitated by loss or damage from any cause reasonably beyond the control of DRADER, such as lightning or other natural and weather-related events or wartime environments; and
- (g) Cover any labor involved in the removal and or reinstallation of warranted Injectiweld Products on site, or any labor required to diagnose the necessity for repair or replacement.

For greater certainty and the avoidance of doubt, DRADER does not warrant the quality of any welds or repairs made by a welder using the Injectiweld Products.

C. Limitation of Liability

For greater certainty and the avoidance of doubt, the warranty provided herein is limited to the remedies provided in Paragraph A1 and A2 above and specifically excludes any responsibility by DRADER for incidental or consequential damages arising from the use of Injectiweld Products, or for any inability to use them either separate from or in combination with any other equipment or products.

To the extent permitted by law, the warranty provided herein is strictly in lieu of: a) any other conditions or warranties, express or implied, oral or written, statutory or otherwise, including, but not limited to, any implied warranty of merchantability or fitness for purpose; and b) any and all obligations and liabilities of DRADER for damages including but not limited to accidental, consequential, or special damages, or any financial loss, lost profits or expenses arising from or out of or in connection with the use or performance of the Injectiweld Products, even if DRADER has been advised of the possibility of such damages. DRADER shall not be liable for any claim made by a third party or made by the customer on behalf of a third party.

If any term or condition of this limited warranty or the application thereof to any person or circumstance will, to any extent, be held to be invalid or unenforceable by applicable laws (including but not limited to consumer protection legislation in the jurisdiction of the customer), the remainder of this limited warranty and the application of that term or condition to persons or circumstances other than those as to which it is held invalid or unenforceable, will not be affected thereby and each term and condition of this limited warranty will be valid and enforced to the fullest extent permitted by law. DRADER and the customer acknowledge and agree that the court having jurisdiction over any dispute in this warranty shall have, and hereby expressly grant to such court, the express power and authority to read down and/or sever any offending provisions herein to the extent required to make any such covenant enforceable. The court is hereby advised and instructed that it is the intention of DRADER and the customer that the provisions of this limited warranty be amended to the minimum extent required to make such provisions reasonable and enforceable in the circumstances, as determined by the court in its discretion. Drader and the customer acknowledge and agree that, for the purposes of this limited warranty, the laws of the country of purchase (the location of DRADER or Authorized Distributor, as applicable, who receives and processes the order of Injectiweld Products for the customer) of the Injectiweld Products shall apply and shall be considered the applicable law herein.